



NOVESKE
RIFLEWORKS LLC

PEQ Light Mount



Tools needed

- 8mm torx wrench
- Flat head screw driver

Instructions

- Locate the two 2mm Allen screws located on the bottom of your PEQ-15 holding the mounting plate to the main body of the laser.
- Carefully loosen the screws as they can have thread lock on them.
- Remove the entire mounting assembly from the main body of the laser
- Remove the flat head mounting nut from the cross screw.
- Remove the washer from the cross screw.
- Remove the mounting side plate from the cross screw noting the orientation.

- Install the light body in the same orientation as the side plate.
- Install the washer and flat head mounting nut.
- Install the entire assembly onto the bottom of the PEQ-15 with the allen screws using a small amount of loctite.
- Loosen the flat blade nut until it contacts the light body, it is now ready to install on the rail.
- Install flashlight head and tail with battery.